

# **JOBE SEA-ESTA**

## INSTALLATION MANUAL

### **STEP 1**

*Inflate mainchamber first*



### **STEP 2**

*Inflate backrest*



### **STEP 3**

*Insert bars*



### **STEP 4**

*Connect buckles*

